
Adjustment of Icon hinge



Vertical Adjustment

- 1. All hinges adjusted together.
- 2. Support underside of door with lever.
- 3. Slacken screw B on each hinge.
- 4. Lift of lower door to desired position.
- 5. Tighten screw B on each hinge.
- 6. Check operation of door.

Side Adjustment

- 1. Hinges adjusted individually.
 - To move door closer to frame
- 2. Slacken screw B & tighten A screws
 - To move door away to frame
- 3. Slacken A screws tighten B screw.
- 4. Check operation of door.

On completion of any adjustment all screws and to be checked to ensure they are tight.